Ergo D-Pro Notebook Stand

TARGUS®

Making Your Mobile Life Easier.®

Visit our Web site at: www.targus.com

Features and specifications are subject to change without notice.

© 2005 Targus Group International, Inc. and Targus Inc.

AWE05US/400-0214-001A

USER'S GUIDE

Making Your Mobile Life Easier.®

BRUSSELS HANNOVER BARCELONA TOKYO MILAN AMSTERDAM SINGAPORE LONDON PARIS NEW YORK LOS ANGELES TORONTO HONG KONG SYDNEY

PMS Black 15%

PMS Black 100%

Table of Contents

Setting Up The D-Pro 4

Cable Management 6

Without Targus Port Replicator 6

With Targus Port Replicator 7

Connecting a Security Cable 8

Port Replicator Module 9

Attention IBM & Toshiba Users 9

Outlining the Height 10

Using the Hook & Loop Fasteners 12

Ergonomic Guidelines 13

Technical Support 14

Warranty 14

TARGUS ERGO D-PRO NOTEBOOK STAND

Introduction

Congratulations on your purchase of the Targus Ergo D-Pro Notebook Stand. The D-Pro is a unique, ergonomically correct desktop notebook stand that allows a notebook computer to be comfortably used as a desktop replacement. The D-Pro provides a compartment for storage of a Targus Port Replicator or hub and cable management for a clean workspace.

The D-Pro incorporates a patent pending document holder. This document holder is designed to create a functional workspace with an optimal viewing distance between documents, screen and keyboard.

Setting Up The D-Pro

1 Press buttons (A) on both sides to raise the D-Pro to desired angle.



2 Open the document holder and flip it towards you.



3 Check that the D-Pro is assembled correctly and carefully place your notebook on the stand as shown.

4 Fold the document holder up into place. Adjust the inclination of the document holder by using the shift buttons (B). Attach your external mouse and keyboard and you're ready to work efficiently and ergonomically.



Cable Management

Without Targus Port Replicator

1 Remove compartment cover (A).

2 Guide cables through as indicated and reinstall compartment cover.



With Targus Port Replicator

1 Remove compartment cover (A).

2 Place the replicator in the cavity.

3 Guide cables through (B) and connect them to the replicator.



4 Connect your notebook and power supply at (C).

5 Replace compartment cover.

Connecting a Security Cable

The D-Pro offers two options for securing your notebook and peripherals; a slot lock or video port lock .

Follow the usage instructions included with your security cable.



Port Replicator Module (Optional)

The Port Replicator Module (PRM) allows you to mount your OEM docking station or port replicator to the D-Pro.

Attention IBM & Toshiba Users

Your docking station/port replicator may be positioned and attached to the PRM with the screw rivets that are provided. Attach your docking station/port replicator to the PRM by screwing the two rivets into the PRM plate and docking station/port replicator before securing to the D-Pro with the knobs.

Alternatively you may use the hook and loop fasteners provided. For instructions, please go to “Outlining the Height” on page 10.

1 Place the PRM onto the D-Pro and screw the knobs onto the plate.



2 Connect your notebook first to your docking station/port replicator and place them together onto the D-Pro, making sure your notebook is supported at (B) and centered.



3 Use the knobs to position the PRM after determining the proper position to attach the docking station/port replicator according to the outlining instructions below.

Outlining the Height

Refer to the instructions for your model of docking station/port replicator:

IBM Thinkpad Dock II: Line up the the holes on the back of your docking station with the holes on the back of the PRM at (D).

HP DC 367B port replicator: Line up the top of your port replicator with the indication lines on the PRM at (E).

Toshiba Advanced port replicator II and III: Line up the top of your port replicator with the indication lines on the PRM at (F).



Port Replicator Module (PRM)

The position where the docking station/port replicator is to be attached to the PRM is now determined.

If you have used the screw rivets to secure your docking station/port replicator, your installation is complete once you secure the PRM to the D-Pro.

Using the Hook & Loop Fasteners

1 Remove the plastic covering from the four hook and loops at (G). With the front of the notebook resting on (B), carefully and firmly push the docking station/port replicator onto the PRM and hold for at least 20 seconds.



2 The docking station/port replicator is now attached to the PRM and the notebook screen should be positioned at the center of the D-Pro.

Your notebook workstation is ready for use.

NOTE: THE POSITION OF THE DOCKING STATION/PORT REPLICATOR CAN BE ADJUSTED TO SUIT SMALLER OR LARGER NOTEBOOKS BY ADJUSTING THE HEIGHT OF THE PRM USING THE TWO KNOBS AT (H).

Ergonomic Guidelines

The following guidelines will help you to create a comfortable and ergonomic working environment.



1 Adjust the armrest of your chair such that it is level with the height of the table or keyboard. In this position, your shoulders should be relaxed;

2 Adjust the screen distance; usually between 20-35 inches (50-90 cm), so that you can comfortably read the display;

3 Angle the screen so that it is vertical (90 degree angle to your line of sight);

4 Ensure the top of the screen is at eye level or just below;

5 When working with documents, use the in-line document holder between the screen and the keyboard.

Technical Support

For technical questions, please visit:

US

Internet: www.targus.com/support.asp

Australia

Internet: www.targus.com/au

Email: infoaust@targus.com

Telephone: 1800-641-645

New Zealand

Telephone: 0800-633-222

Product Registration

Targus recommends that you register your Targus accessory shortly after purchasing it. Go to: http://www.targus.com/registration.asp

You will need to provide your full name, email address, phone number, and company information (if applicable).

Warranty

Targus warrants this product to be free from defects in materials and workmanship for one year. If your Targus accessory is found to be defective within that time, we will promptly repair or replace it. This warranty does not cover accidental damage, wear and tear, or consequential or incidental loss. Under no conditions is Targus liable for loss of, or damage to a computer; nor loss of, or damage to, programs, records, or data; nor any consequential or incidental damages, even if Targus has been informed of their possibility. This warranty does not affect your statutory rights.

Features and specifications subject to change without notice. All trademarks and registered trademarks are the property of their respective owners. © 2005, Targus Group International, Inc. and Targus, Inc., Anaheim, CA 92806 USA.